

PUMP OUT PLUGS

The **Pump-Out Plug** is available with a variety of threads allowing installation to the bottom of the tubing string to isolate the tubing from the annulus. To remove the plug, pressure is applied to the tubing and the Pump-Out Plug is removed to allow full opening. The pump-out pressure value is easily adjusted in the field by adding or removing shear screws. Also available with ball seat.

Special Features

- >Ball seat available
- >Adjustable shear value (available in high shear)
- >Special Pump-out Plug design available



**Pump-Out Plug
w/ Shear
Screws**

Product Specifications

Tubing Size (inches)	Tool OD (inches)	Tool ID (inches)	Thread Connection Box Up
1.050	1.660	-	1.050 EUE
1.315	1.900	1.20	1.315 EUE
1.660	2.062	1.38	1.660 NUE
	2.200	1.38	1.660 EUE
1.900	2.500	1.50	1.900 EUE
	2.200	1.50	1.900 NUE
2-3/8	3.060	2.00	2-3/8 EUE
2-7/8	3.670	2.50	2-7/8 EUE
3-1/2	4.500	3.46	3-1/2 EUE
		2.88	3-1/2 EUE
4-1/2	5.560	4.00	4-1/2 EUE
			4-1/2 LTC
5-1/2	6.000	5.13	5-1/2 LTC
6-5/8	7.390	6.23	6-5/8 LTC
7	7.650	6.60	7" LTC
8-5/8	9.620	8.18	8-5/8 LTC
9-5/8	10.620	9.17	9-5/8 LTC



**Pump-Out Plug
w/ Shear
Screws and Ball
Seat**

ENVISION DOWNHOLE, LLC

801 S. Pagewood Ave. Suite 7 Odessa, TX 79761

T: 432-217-8644 | envisiondownhole.com

© 2020 Envision Downhole, LLC. All rights reserved.



ENVISION DOWNHOLE, LLC

801 S. Pagewood Ave. Suite 7 Odessa, TX 79761

T: 432-217-8644 | envisiondownhole.com

© 2020 Envision Downhole, LLC. All rights reserved.



ENVISION DOWNHOLE, LLC

801 S. Pagewood Ave. Suite 7 Odessa, TX 79761

T: 432-217-8644 | envisiondownhole.com

© 2020 Envision Downhole, LLC. All rights reserved.

